



SEAT ADJUSTMENT

First, adjust the driving position so that you are able to press down the clutch pedal with your left foot. The seat distance adjustment is under the front edge of the seat. Lift the lever (A) up to move the seat. Seat height or steering wheel cannot be adjusted. The tilt of the back of the seat (B) is adjustable on both sides of the seat.




SEAT BELT

Make sure that the seat belt does not stay loose when you fasten the seat belt.

GEARS

The simulator has six gears and a reverse gear. Before shifting, press the clutch fully down. Do not use force when shifting gears.

If you are driving with an automatic transmission, the 3rd gear is D (drive). The reverse gear is in the same place as normal. The car can be changed for automatic transmission from the touchscreen.



START TO DRIVING

The start button is located in the center console, next to the gear stick.

1. Manual transmission car
 - Keep the parking brake (P) engaged and the gear on neutral
 - Press the clutch pedal down
 - Touch the start button (START)
2. Automatic transmission car
 - Keep the parking brake (P) engaged
 - Press the brake pedal down
 - Touch the start button (START)






The parking brake is an electric button.

!!! The parking brake button (P) is at the top of the indicator lever. CHECK -button.

LIGHT SWITCH

The simulator driving light switch is located in the center console. Turn the light switch to the right to turn on the headlights (low beam).


-  Lights off
-  Parking lights (front and back lights on)
-  Driving lights (low beam)



INDICATORS AND HIGH BEAM

The turn signal (indicator) is on the left side of the steering wheel. Lift the lever up (1) to flash to the right and press the lever down (2) to flash to the left. The turn signal turns off automatically when you straighten the steering wheel.

You can also turn on the high beam from the indicator lever. Push the lever forward (A) to turn on the high beam. Pull the lever towards you (B) to turn on the low beam.



TOUCH SCREEN

Many functions such as hazard warning lights, window wipers and rearview mirror dimming can be found on the touch screen. You can also selected the training program from the touch screen.



FOR TRAINING

Listen to the instructions given by the simulator and do the given tasks with out hurry. If you rush too much, you may have to do the task again.

You should drive the driving speed given in the task. If you drive too slowly, you may need to repeat the training assignment.